



# Seat Cushion Adjustment



## 1 Seat Cushion Extension

You can extend or shorten the bottom seat cushion to vary leg support and to optimize your comfort.

**Extend the cushion:** Drivers with longer legs may find that extending the cushion increases comfort by providing more leg support.

**Shorten the cushion:** Drivers with shorter legs may benefit from shortening the cushion.

### How do I adjust the seat cushion?

1. Ensure the Glide Lock is locked.
2. Pull the Seat Cushion Extension lever up and slide the cushion:
  - Forward to extend the cushion
  - Back to shorten the cushion

**TIP** If the cushion is hard to move, use your hand to pull or push the seat cushion as you pull the lever.

## 2 Thigh Support

You can adjust the front of the bottom seat cushion up or down for additional thigh support.

**Flat (default):** Medium thigh support

**Up:** Increases thigh support

**Down:** Decreases thigh support

### How do I adjust thigh support?

#### To increase thigh support:

1. Squeeze the Thigh Support handle and at the same time:
2. Firmly lean back into the seat.
3. Pull the front of the cushion up.

#### To decrease thigh support:

1. Squeeze the Thigh Support handle and at the same time:
2. Push the front of the cushion down.

#### To return thigh support to flat:

1. Squeeze the Thigh Support handle and at the same time:
2. Pull or push the front of the cushion to return to flat.